

GasGuard Manual Interlocking System

| Overview |

The GasGuard Manual Kitchen Interlock is designed to meet the requirements IGEM/UP/19 and BS6173:2009 (where all appliances are fitted with Flame Failure Devices), with numerous additional safety features added based on our 35 years of experience in the industry.

This cost effective non-proving system combines unrivalled functionality with the same user friendly interface as all Flamefast systems.

With individual alarm indications for external devices and a dedicated engineers button, diagnosis of any site issues can be done quickly and hassle free.

| Key Features |

- No commissioning required
- 24VDC auxiliary power output
- Interfaces for Gas Sensors & CO2 Monitors, Ventilation Interlocks, Building Management Systems (BMS), Remote Emergency Stop Buttons and Fire Alarm Systems
- Built in time delays to avoid nuisance tripping
- Engineers Mode for easy fault diagnosis
- **UK MANUFACTURED**



Installer Selectable Options

- Gas Availability Timer (1-15 Hours or Constant)
- 2x 0-10V Inputs (Preset programs)

Technical Specification

Power Supply	230VAC
Power Output (Gas Solenoid)	230VAC
IP Rating	IP65 (Providing rear entry sealed)
Approval	CE

External Device Interfaces

BMS	Volt Free Contact (Valve Status) – Rated 230V 5A Max
24V Out	Auxiliary Power Supply (170mA Max) (to be used for Gas Sensors, Transmitters etc.)
Gas Sensor	24V Signal to monitor external VFC
Ventilation	24V Signal to monitor external VFC
Remote Stop	24V Signal to monitor external VFC
Fire Alarm	24V Signal to monitor external VFC
2x 0-10V In	Monitors external devices providing a 0-10V signal (programs preset – see Wiring Diagram for details)

Dimensions

Height	180 mm
Width	130 mm / 140 mm Including Hinge
Depth	60 mm / 85 mm Including Stop Button

Basic Operation

When switched on via the key switch the GasGuard Manual system provides gas to the kitchen and monitors all external interfaces such as ventilation systems.

Upon receiving a fault signal from any external devices, the GasGuard will ensure that the gas is isolated to prevent any potential issues.

The easy to use engineers button can be used to display any faults with the system and allow gas through for commissioning and purging.

Part Numbers & Options/Accessories

Part No	Description
GGM-PO	GasGuard Manual Panel Only
SVXX	Gas Solenoid Valve (See Datasheet for Part No.)